

**ACCESSORIES FOR THE CONTROL PANELS TYPES 1QM/CE, 1QT/CE, 1QMD/CE, 1QTD/CE, Q2PM/CE, Q2PT/CE, Q2PMD/CE, Q3PTD/CE Q3PM/CE, Q3PT/CE, Q3PMD/CE, Q3PTD/CE, SLC/M, SLC/T, SLC/C/M, SLC/C/T, SLC1/M AND SLC1/T**

**SPACER WITH FILTER FOR LEVEL TRANSDUCERS TYPE TDL1**

The spacer filter type FTL1 is supplied as an optional in cases where a level transducer is fixed in a submerged tank. The spacer is used to lift the sensor from the bottom of the tank (10cm) thus allowing there to always be a minimum quantity of liquid in the tank, avoiding the pump from running dry as can happen in the case of an incorrect reading at low levels.

TYPE FTL1



CODE 700630

**SPACER WITH FILTER FOR LEVEL TRANSDUCERS TYPE TDL1**

The filter type TDL2 is supplied as an optional in cases where a level transducer is fixed in tanks or submerged biological tanks. The filter type FTL2 is used to protect the sensor from any damage caused by unwanted objects floating in the tank.

TYPE FTL2



CODE 700635